



CarCleaner auto S20



I INTENDED USE

This vacuum cleaner is intended for domestic use only, not for industrial. This special vacuum cleaner is neither suitable nor equipped for carpet or hard floor cleaning and therefore doesn't include the necessary accessories. The vacuum cleaner complies with recognized rules of technology and relevant safety regulations.

Use the vacuum cleaner only according to the manual. Use only original filters, accessories, spare parts. Do not vacuum hazardous, toxic, sharp-edged, incandescent, glowing, hot or burning, damp or liquid, highly inflammable or explosive surfaces, substances and gases. The manufacturer is not responsible for any damage caused by unintended use or incorrect operation.

II DISPOSAL OF PACKAGING AND FILTER

The biodegradable packaging protects the cleaner during transportation. Dispose of unneeded packaging at appropriate recycling point. But keep this instructions manual. Dispose of used filter with household waste.



III SAFETY WARNINGS

For safety use the vacuum cleaner:

- only connected as on data plate
- only fitted with its folded filter
- only undamaged
- not by children
- not by physically, sensory or mentally impaired persons
- away from head, hair, clothing
- away from sharp corners
- away from hot surfaces
- protected from moisture and heat

Do not carry, nor pull the vacuum cleaner by the cable.

Always switch off and unplug the cleaner when not in use and before any maintenance.

To disconnect from mains, pull the plug, not the cable.

The vacuum cleaner is not a toy. Never immerse cleaner in water.

IV IN CASE OF DISORDER

Only qualified technicians are authorized to repair the cleaner. Think about having the cleaner repaired before disposing of it! In case of disposal the cleaner may not be treated as household waste. Turn it over to the local collecting point for electrical and electronic waste. All parts –size permitting– are marked for recycling its' materials and components.



CarCleaner auto S20



V ASSEMBLY

- 1 Insert the hose **j** in the hose inlet on side **a** by applying a slight pressure and by turning it in tightly.
- 2 Fit the appropriate nozzle **k** or **l** by twisting it firmly onto the handle of the hose **j**.
- 3 Plug the cable **i** into an electrical socket.
- 4 Switch on the vacuum cleaner by pressing the on/off switch **f**.

VII MAINTENANCE

- 7 Empty the dust cassette **a** frequently: Open both clip hinges **e** on top and below, take off the dust cassette **a** and empty the dust compartment.
- 8 Clean the filter: Twist off the folded filter **b**. Clean the filter by brushing, vacuuming or blowing. If necessary rinse off the folded filter **b** under lukewarm water. Insert back inside only when totally dried.
- 9 Insert the folded filter **b** firmly on the motor block side **c**, then refit the dust cassette **a** into the cleaner. Close both clip hinges **e** on top and below.

VI HOW TO USE

- 5 For vacuuming: hang the cleaner by the shoulder strap **d** or set it down on a stable place. Always ensure that the air can flow freely out on the blowing side **h**. The bristles strip of the upholstery nozzle **k** can be removed, release by pressing in the middle.
- 6 For blowing: reposition the hose **j** on the blowing side **h**. Inflate childrens padding pools, waterballs, air mattresses, etc. with the blowing nozzle **m** on the hose handle **j**. Rapid deflation by reconnecting the hose **j** to the suction side **a**.

VIII SPARE PARTS AND ACCESSORIES

Can be ordered as follows:

Art. n°	Description
290482	Folded filter b
290102	Clip hinges 2-parts e
290162	Flexible hose j
290152	Upholstery nozzle k
290142	Crevice nozzle l
290132	Blowing nozzle m
391711	Round brush
292152	Large upholstery nozzle
290171	Micro-KIT mini accessories
290504	eXtra-Filter-System with basket, textile and motor filter
	Quote codes on the data plate (underneath the appliance).